



Note : Sensor Should Be Submerged In Water For About 15 Minutes Before Installation

CORRECT SENSOR DEPTH

Approximately 3' to 4' Of Compacted Cover In Turf Areas

CORRECT SENSOR PLACEMENT IS DETERMINED BY A CALSENSE FIELD TECHNICIAN. DIAGRAM REPRESENTS CORRECT SENSOR WIRING ONLY.

Locate Sensor At Base Of Rootball, Depth Will Vary With Size Of Plant Material. Cover With Compacted Soil

CS CALSENSE