

 **TABLE OF CONTENTS****INTRODUCTION**

INTRODUCTION  
CALSENSE PHILOSOPHY  
CALSENSE SERVICE  
HOW TO CONTACT CALSENSE

**ABOUT COMMAND CENTER**

COMMAND CENTER DESCRIPTION  
COMMAND CENTER FOR WINDOWS  
CENTRAL COMPUTER SOFTWARE  
CENTRAL COMPUTER SPECIFICATIONS

**HOW TO USE THIS MANUAL**

HOW TO USE THIS MANUAL  
INCORPORATING CHANGES TO THIS MANUAL

**HOW TO PRINT REPORTS**

HOW TO PRINT REPORTS

**TABLE OF CONTENTS**

TABLE OF CONTENTS  
LIST OF CHANGES

**SECTION 1****ADMINISTRATOR / USER SETUP**

- 1.0 ADMINISTRATOR / USER SETUP
- 1.1 ADDING A USER
- 1.2 EDITING A USER
- 1.3 DELETING A USER
- 1.4 RESETTING A USER'S PASSWORD
- 1.5 LOGIN
- 1.6 LOGOUT
- 1.7 IMPORT
- 1.8 EXPORT

**SECTION 2****PREFERENCE SETUP**

- 2.0 PREFERENCES

**SECTION 3****COMMUNICATIONS SETUP**

- 3.0 COMMUNICATION SETUP
- 3.1 VIEW COMMUNICATIONS
- 3.2 ABORT COMMUNICATIONS
- 3.3 SHUTDOWN COMMUNICATIONS

**SECTION 4****SITE / CONTROLLER SETUP**

- 4.0 SITE / CONTROLLER SETUP
- 4.1 ADDING A NEW SITES / CONTROLLERS
- 4.2 CONTROLLER COMMUNICATIONS SETUP
- 4.3 EDITING A CONTROLLER
- 4.4 DELETING A SITE / CONTROLLER
- 4.5 PRINTING CONTROLLER INFORMATION

**SECTION 5****CONTROLLER ASSIGNMENT SETUP**

- 5.0 CONTROLLER ASSIGNMENT SETUP

**SECTION 6**

**SPEED COMMUNICATIONS**

- 6.0 SPEED COMMUNICATIONS
- 6.1 GET ALERTS
- 6.2 GET PROGRAM DATA
- 6.3 GET STATION HISTORY
- 6.4 GET ALL DIAGNOSTICS
- 6.5 SEND NO WATER DAYS
- 6.6 CONTROLLER ON
- 6.7 CONTROLLER OFF
- 6.8 DIRECT ACCESS
- 6.9 GET MANUAL PROGRAMS
- 6.10 SEND ACCESS CONTROL CODES
- 6.11 GET LIGHTS
- 6.12 CLEAR MAINLINE BREAK
- 6.13 MASTER VALVE OVERRIDE
- 6.14 CLEAR HOLD OVER
- 6.15 SET TIME AND DATE

**SECTION 7**

**DIRECT ACCESS**

- 7.0 DIRECT ACCESS
- 7.1 DIRECT ACCESS ET1
- 7.2 DIRECT ACCESS ET2000 (400 SERIES)
- 7.3 DIRECT ACCESS ET2000 (500 SERIES)
- 7.4 DIRECT ACCESS ET2000e

**SECTION 8**

**ALERT SETUP**

- 8.0 ALERT SETUP
- 8.1 NEW ALERT FILTER
- 8.2 SET ALERT FILTER AS DEFAULT
- 8.3 REMOVE DEFAULT ALERT FILTER
- 8.4 DELETE ALERT FILTER
- 8.5 ALERT FILTERS

**SECTION 9**

**ET2000 ACCESS CONTROL SETUP**

- 9.0 SETUP ET2000 ACCESS CONTROL
- 9.1 CREATING AN ACCESS GROUP
- 9.2 SENDING AN ACCESS GROUP

**SECTION 10**

**WEATHER STATION SETUP**

- 10.0 WEATHER STATION SETUP

**SECTION 11**

**TASK SETUP**

- 11.0 SETTING UP A TASK
- 11.1 PERFORMING / SCHEDULING A TASK
- 11.2 COMMUNICATIONS TASK SCHEDULER
- 11.3 VIEWING DAILY SCHEDULE
- 11.4 DELETING A SCHEDULED TASK

**SECTION 12**

**WEATHER SHARING**

- 12.0 SHARING WEATHER TASK
- 12.1 GATHERING WEATHER DATA
- 12.2 SHARING WEATHER DATA

**SECTION 13**

**RAIN POLLING**

- 13.0 RAIN POLLING SETUP

**SECTION 14**

**WINTER SHUTDOWN**

- 14.0 WINTER SHUTDOWN

**SECTION 15**

**TERMINATE WINTER SHUTDOWN**

- 15.0 TERMINATE WINTER SHUTDOWN



**SECTION 16**

**CONTROLLER PROGRAM DATA**

TAB A

ET1 IRRIGATION CONTROLLER

- 16.0 (TAB A) ET1 CONTROLLER PROGRAM DATA
- 16.1 ET1 CONTROLLER SCHEDULE
- 16.2 ET1 CONTROLLER SCHEDULE STATION ASSIGNMENT
- 16.3 ET1 CONTROLLER FLOW
- 16.4 ET1 CONTROLLER WEATHER
- 16.5 ET1 CONTROLLER SETUP
- 16.6 ET1 SAVE PROGRAM DATA
- 16.7 ET1 SEND PROGRAM DATA
- 16.8 ET1 PRINT PROGRAM DATA
- 16.9 ET1 GET PROGRAM DATA

TAB B

ET2000 (400 SERIES) IRRIGATION CONTROLLER

- 16.0 (TAB B) ET2000 (400 SERIES) CONTROLLER PROGRAM DATA
- 16.1 ET2000 (400 SERIES) CONTROLLER SCHEDULE
- 16.2 ET2000 (400 SERIES) CONTROLLER SCHEDULE STATION ASSIGNMENT
- 16.3 ET2000 (400 SERIES) CONTROLLER FLOW
- 16.4 ET2000 (400 SERIES) CONTROLLER WEATHER
- 16.5 ET2000 (400 SERIES) CONTROLLER SETUP
- 16.6 ET2000 (400 SERIES) SAVE PROGRAM DATA
- 16.7 ET2000 (400 SERIES) SEND PROGRAM DATA
- 16.8 ET2000 (400 SERIES) PRINT PROGRAM DATA
- 16.9 ET2000 (400 SERIES) GET PROGRAM DATA

TAB C

ET2000 (500 SERIES) IRRIGATION CONTROLLER

- 16.0 (TAB C) ET2000 (500 SERIES) CONTROLLER PROGRAM DATA
- 16.1 ET2000 (500 SERIES) CONTROLLER SCHEDULE
- 16.2 ET2000 (500 SERIES) CONTROLLER SCHEDULE STATION ASSIGNMENT
- 16.3 ET2000 (500 SERIES) CONTROLLER FLOW
- 16.4 ET2000 (500 SERIES) CONTROLLER WEATHER
- 16.5 ET2000 (500 SERIES) CONTROLLER SETUP
- 16.6 ET2000 (500 SERIES) SAVE PROGRAM DATA
- 16.7 ET2000 (500 SERIES) SEND PROGRAM DATA
- 16.8 ET2000 (500 SERIES) PRINT PROGRAM DATA
- 16.9 ET2000 (500 SERIES) GET PROGRAM DATA

TAB D

ET2000e IRRIGATION CONTROLLER

- 16.0 (TAB D) ET2000e CONTROLLER PROGRAM DATA
- 16.1 ET2000e CONTROLLER SCHEDULE
- 16.2 ET2000e CONTROLLER SCHEDULE STATION ASSIGNMENT
- 16.3 ET2000e CONTROLLER FLOW
- 16.4 ET2000e CONTROLLER WEATHER
- 16.5 ET2000e CONTROLLER SETUP
- 16.6 ET2000e SAVE PROGRAM DATA
- 16.7 ET2000e SEND PROGRAM DATA
- 16.8 ET2000e PRINT PROGRAM DATA
- 16.9 ET2000e GET PROGRAM DATA
- 16.10 ET2000e (-F) OPTION

**SECTION 17**

**MANUAL PROGRAMS**

- 17.0 MANUAL PROGRAMS
- 17.1 ET1 / ET2000 CONTROLLERS (400 SERIES) MANUAL PROGRAMS
- 17.2 ET2000 CONTROLLERS (500 SERIES) MANUAL PROGRAMS



**SECTION 18**

**LIGHTS**

18.0 LIGHTS

**SECTION 19**

**COMMUNICATIONS LOG**

19.0 COMMUNICATIONS LOG

**SECTION 20**

**ALERTS**

*(DIAGNOSTIC REPORTS)*

- 20.0 ALERTS
- 20.1 ALERTS REPORT
- 20.2 ALERTS PAGE REPORT CONTENTS
- 20.3 GET ALERTS
- 20.4 LATEST ALERTS

**SECTION 21**

**STATION HISTORY**

*(DIAGNOSTIC REPORTS)*

- 21.0 STATION HISTORY
- 21.1 STATION HISTORY REPORT
- 21.2 STATION HISTORY REPORT CONTENTS

**SECTION 22**

**CONTROLLER LIST**

*(CENTRAL REPORTS)*

- 22.0 CONTROLLER LIST
- 22.1 CONTROLLER LIST REPORT CONTENTS

**SECTION 23**

**TASK LIST**

*(CENTRAL REPORTS)*

- 23.0 TASK LIST
- 23.1 TASK LIST REPORT CONTENTS

**SECTION 24**

**DISABLED COMMUNICATIONS**

*(CENTRAL REPORTS)*

- 24.0 DISABLED COMMUNICATIONS
- 24.1 DISABLED COMMUNICATIONS REPORT CONTENTS

**SECTION 25**

**NO REPORT GATHERING**

*(CENTRAL REPORTS)*

- 25.0 NO REPORT GATHERING
- 25.1 NO REPORT GATHERING REPORT CONTENTS

**SECTION 26**

**WATER MANAGEMENT**

*(WATER REPORTS)*

- 26.0 WATER MANAGEMENT
- 26.1 WATER MANAGEMENT REPORT
- 26.2 WATER MANAGEMENT REPORT CONTENTS

**SECTION 27**

**WATER USAGE**

*(WATER REPORTS)*

- 27.0 WATER USAGE
- 27.1 WATER USAGE REPORT
- 27.2 WATER USAGE REPORT CONTENTS

**SECTION 28**

**CONTROLLER SUMMARY**

*(WATER REPORTS)*

- 28.0 CONTROLLER SUMMARY
- 28.1 CONTROLLER SUMMARY REPORT
- 28.2 CONTROLLER SUMMARY REPORT CONTENTS



**SECTION 29****STATION SUMMARY  
(WATER REPORTS)**

- 29.0 STATION SUMMARY
- 29.1 STATION SUMMARY REPORT
- 29.2 STATION SUMMARY REPORT CONTENTS

**SECTION 30****USER LOG SETUP**

- 30.0 USER LOG SETUP
- 30.1 USER LOG REPORT CONTENTS

**SECTION 31****BACK UP AND RESTORE**

- 31.0 BACKUP AND RESTORE
- 31.1 BACKUP
- 31.2 RESTORE

**SECTION 32****COMMUNICATIONS SERVER STATUS**

- 32.0 COMMUNICATIONS SERVER STATUS
- 32.1 COMMUNICATIONS SERVER STATUS SCREEN CONTENTS

**SECTION 33****RRe INTERFACE**

- 33.0 RRe INTERFACE
- 33.1 PREFERENCES
- 33.2 REGIONS
- 33.3 CONTROLLERS
- 33.4 HELP

**SECTION 34****POC SUMMARY  
(WATER REPORTS)**

- 34.0 P.O.C. SUMMARY
- 34.1 P.O.C. SUMMARY REPORT
- 34.2 P.O.C. SUMMARY REPORT CONTENTS

 **LIST OF CHANGES**

**CHANGE 1**

**SECTION 7 DIRECT ACCESS**

Section 7.4 DIRECT ACCESS ET2000e Date incorporated 20 September 2006

**SECTION 16 CONTROLLER PROGRAM DATA TAB D**

Section 16.10 ET2000e (-F) option Date incorporated 20 September 2006

**SECTION 33 RRe-INTERFACE**

Entire section added to manual Date incorporated 20 September 2006

**SECTION 34 P.O.C SUMMARY**

Entire section added to manual Date incorporated 20 September 2006

MAKE SURE THAT CHANGE 1 HAS BEEN INCORPORATED INTO THIS MANUAL  
PRIOR TO INCORPORATING CHANGE 2

**CHANGE 2**

**SECTION 2 PREFERENCES**

Section 2.0 Communication Tab Date incorporated 30 March 2007

**SECTION 8 ALERT SETUP**

Section 8.2 Alert Filters Thru 8.5 Alert Filters Date incorporated 30 March 2007

**SECTION 16D ET2000e PROGRAM DATA**

Section 16.1 Controller Schedule  
(Addition of Program Priorities)

Section 16.3 Controller Flow (Flow checking section) Date incorporated 30 March 2007

**SECTION 20 ALERTS**

Section 20.0 ALERTS Date incorporated 30 March 2007

