

---

## Tech Tip of the Month

### Irrigation Details

On the Calsense ET2000e or ET2000 (500 series) controller, how do you find out which stations are irrigating, soaking, and where each one is in its cycle? From the Status screen, press **(live screens) > Irrigation Details**. Or, **Main Menu > Reports > Live Screens > Irrigation Details**.

The Irrigation Details screen displays the following information:

- **STN:** Each station that is on the list to currently irrigate.
- **WHY:** The reason a station is irrigating, for example, Test, Programmed, Manual, Walk-Thru, etc.
- **HOLD:** If a station has left-over minutes that didn't irrigate due to water window restrictions, these minutes can be irrigated after programmed irrigation finishes, providing there's enough time in the water window.
- **TOTAL:** Total time in minutes that a station will irrigate; the minutes count down during irrigation. (If more than one cycle will be run, remaining time is displayed.)
- **CYCLE:** Counts down minutes remaining for currently-irrigating stations.
- **SOAK:** The minimum amount of minutes remaining until the controller will try to water a station again.

Clearing a station stops it from irrigating at this time and removes it from the list. Press PLUS or MINUS to highlight different stations. Press Clear Station.